



EUR2

P70/P5 DIP SWITCHES SETTING : 1(Pulse/ICT)

Supported bill Euro 5, 10

2 bills.

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★	1 Pulse / Euro 5	OFF	OFF	OFF							
	2 Pulse / Euro 5	OFF	OFF	ON							
	3 Pulse / Euro 5	OFF	ON	OFF							
	4 Pulse / Euro 5	OFF	ON	ON							
	5 Pulse / Euro 5	ON	OFF	OFF							
	10 Pulse / Euro 5	ON	OFF	ON							
	20 Pulse / Euro 5	ON	ON	OFF							
	100 Pulse / Euro 5	ON	ON	ON							
	Fast output Pulse <small>Lo= 50ms Hi=100ms</small>				ON						
★	Slow output Pulse <small>Lo= 50ms Hi=300ms</small>				OFF						
	Inhibit level Active Low					ON					
★	Inhibit level Active High					OFF					
★	Accept Euro 5						ON				
	Reject Euro 5						OFF				
★	Accept Euro 10							ON			
	Reject Euro 10							OFF			
	Rseerved								ON		
★	Rseerved								OFF		
	Rseerved									ON	
★	Rseerved									OFF	
	Rseerved										ON
★	Rseerved										OFF

★ Manufacture setting

Note: (1) Please reset the bill acceptor after set the dip switch.

(2) Dip switches 1 to 5 are only used for pulse protocol.

DIP SWITCHES SETTING : 2

	FUNCTION	SW1	SW2	SW3	SW4
★	Pulse Normal High	ON			
	Pulse Normal Low	OFF			
★	Pulse Protocol		ON		
	ICT Protocol		OFF		
	Harness Disable			ON	
★	Harness Enable			OFF	
	Manufacture Default				ON
★	System Default				OFF

★ Manufacture setting

Note: (1) Please reset the bill acceptor after set the dip switch.

(2) Dip switches 1 & 3 are only used for pulse protocol.

