



GEL7

P70/P5 DIP SWITCHES SETTING : 1(Pulse/ICT)

Supported bill Lari 1, 2, 5, 10, 20, 50, 100 7bills.

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★	1 Pulse / Lari 1	OFF	OFF	OFF							
	2 Pulse / Lari 1	OFF	OFF	ON							
	3 Pulse / Lari 1	OFF	ON	OFF							
	4 Pulse / Lari 1	OFF	ON	ON							
	5 Pulse / Lari 1	ON	OFF	OFF							
	10 Pulse / Lari 1	ON	OFF	ON							
	20 Pulse / Lari 1	ON	ON	OFF							
	100 Pulse / Lari 1	ON	ON	ON							
	Fast output Pulse <small>Lo= 50ms Hi=100ms</small>				ON						
★	Slow output Pulse <small>Lo= 50ms Hi=300ms</small>				OFF						
	Inhibit level Active Low					ON					
★	Inhibit level Active High					OFF					
★	Accept Lari 1 & 2						ON				
	Reject Lari 1 & 2						OFF				
★	Accept Lari 5 & 10							ON			
	Reject Lari 5 & 10							OFF			
★	Accept Lari 20								ON		
	Reject Lari 20								OFF		
★	Accept Lari 50									ON	
	Reject Lari 50									OFF	
★	Accept Lari 100										ON
	Reject Lari 100										OFF

★ Manufacture setting

Note: (1)Please reset the bill acceptor after set the dip switch.

(2)Dip switches 1 to 5 are only used for pulse protocol.

DIP SWITCHES SETTING : 2

	FUNCTION	SW1	SW2	SW3	SW4
★	Pulse Normal High	ON			
	Pulse Normal Low	OFF			
★	Pulse Protocol		ON		
	ICT Protocol		OFF		
	Harness Disable			ON	
★	Harness Enable			OFF	
	Ignore Sensor Problem(Note 1)				ON
★	Acknowledge Sensor Problem (Note 2)				OFF

★ Manufacture setting

Note : (1) Sensor 6 problem occurred ==>> BA will be still in working order.

(The face LED will be flashing in short green about 2 seconds everytime you restart BA.)

(2) BA will stop to work when it acknowledges Sensor 6 problem occurred.

(The face LED will be flashing in red.)

