



HNL5

P70/P5 DIP SWITCHES SETTING : 1(IGT Protocol)

Supported bill L 10, 20, 50, 100, 500 5bills.

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★ Reserved	OFF	OFF	OFF							
	OFF	OFF	ON							
	OFF	ON	OFF							
	OFF	ON	ON							
	ON	OFF	OFF							
	ON	OFF	ON							
	ON	ON	OFF							
	ON	ON	ON							
				ON						
				OFF						
				ON						
					ON					
					OFF					
★ Accept L 10						ON				
★ Reject L 10						OFF				
★ Accept L 20							ON			
★ Reject L 20							OFF			
★ Accept L 50								ON		
★ Reject L 50								OFF		
★ Accept L 100									ON	
★ Reject L 100									OFF	
★ Accept L 500										ON
★ Reject L 500										OFF

★ Manufacture setting

Note: (1) Please reset the bill acceptor after set the dip switch.

(2) Dip switches 1 to 5 are only used for pulse protocol.

DIP SWITCHES SETTING : 2

FUNCTION	SW1	SW2	SW3	SW4	
★ Reserved	ON				
	OFF				
		ON			
		OFF			
					ON
					OFF
★ Ignore Sensor Problem(Note 1)				ON	
★ Acknowledge Sensor Problem (Note 2)				OFF	

★ Manufacture setting

Note : (1) Sensor 6 problem occurred ==>>> BA will be still in working order.

(The face LED will be flashing in short green about 2 seconds everytime you restart BA.)

(2) BA will stop working when it acknowledges Sensor 6 problem occurred.

(The face LED will be flashing in red.)

